

PIONEER

COOKING GRILL COMBO USE AND MAINTENANCE

IMPORTANT:




- ALWAYS CLEAN AND DRY YOUR GRILL BEFORE PACKING IT AWAY IN THE CARRY BAG
- ALLOW GRILL TO COOL FOR AT LEAST 30 MINUTES BEFORE REMOVING FROM THE GROUND AND CLEANING

Contents:

- | | | |
|----------------|--------------------------|-----------------|
| A. Stake | D. Lower Grill/ Hotplate | G. Hanger x 2 |
| B. Tube Sleeve | E. Locking Pin | H. Striking Cap |
| C. Stop Collar | F. Upper Grill | I. Carry Bag |

Set up instructions:

- Place Striking Cap (H) on top of Stake (A) before hammering. Failure to use the Striking Cap may result in damage to the Stake
- Hammer Stake into ground approximately 20-30cm and remove Striking Cap (H)
- With the hole on the upper end, slide Tube Sleeve (B) towards the bottom of the stake until hole is aligned with the middle hole in Stake (A)
- Slide Stop Collar sleeve (C) towards the bottom of the Tube Sleeve (B) and fasten. This height can be adjusted later to suit your cooking
- Slide Lower Grill/Hotplate (D) on top of the Stop Collar (C) and fasten
- Put Locking Pin (E) through holes on Tube Sleeve (B) and Stake (A) and secure
- Slide on Upper Grill (F)
- Slide on Hangers (G) and Cap (H). Please note, depending on height of grills, cap may not be required



Specifications:

- Dimensions: 93L x 69W x 70Hcm
Lower Cooking Area: 92L x 41.5Wcm
Upper Cooking Area: 41L x 41Wcm
Material: Heavy gauge hot rolled steel
Weight: 12.5kg approx



Distributed by Companion Brands
Bundoora VIC 3083 www.companionbrands.com.au
Customer Service: 1300 555 197